



(64/94)





(54)



### Changeover between 12-hour system and 24-hour system

While pressing **A**, press **B** to switch between 12-hour system and 24-hour system.



### (Independent correction)

Correction of any digit, if not required, can be skipped by pressing the **B** button repeatedly.

### (Reversion to normal time display)

The watch reverts to the normal time display if the **B** button is pressed, regardless of the digit setting mode.

Calendar system: Auto-calendar pre-programmed until the year 2009.