



(Independent correction)

Correction of any digit, if not required, can be skipped by pressing the [B] button repeatedly.

(Reversion to normal time display)

The watch reverts to the normal time display if the [B] button is pressed, regardless of the digit setting mode.

Calendar system: Auto-calendar pre-programmed until the year 2009.