

(Independent correction) Correction of any digit, if not required, can be skipped by pressing the button repeatedly. (Reversion to normal time display) The watch reverts to the normal time display if the button is pressed, regardless of the digit setting mode.